




# HYDROMATIC INSTRUCTIONS



## 1. UNDERSTANDING YOUR WATCH

Unlike a standard battery-powered watch, a STORM Automatic is a mechanical instrument powered by the movement of your wrist. A weighted rotor inside the case spins as you move, winding a mainspring to store energy.

Feature	Specification
Running Time	Approximately 42 hours
Accuracy*	-20 to +40 sec/day

- \*Accuracy depends on your daily conditions, such as the length of time worn, temperature, your arm movement, and whether the mechanism is fully wound.
- 

## 2. INITIAL WINDING (STARTING THE WATCH)

- **Restarting:** On first use or if the watch has completely stopped, manually turn the crown clockwise approximately 30-40 times to power the mechanism.
  - **Caution:** Be careful not to overwind, as this can cause damage to the mechanism.
  - **Automatic Power:** Once worn on the wrist, the watch will obtain power automatically through your daily movement. However, we do recommend winding it regularly to maintain optimum power.
- 

## 3. SETTING THE TIME & DATE

- **Setting the Time:** Pull the crown out to its furthest point, the 2nd position. Turn the crown to adjust the hour and minute hands. Push the crown completely back to the normal position to restart the second hand.
- **Setting the Date:** Pull the crown out halfway to the 1st position. Turn the crown counter-clockwise to change the date. After the date is set, push the crown back in fully.

**IMPORTANT :** Do **NOT** manually adjust the date between **9:00 PM and 1:00 AM**. If the date is set during this window, it may not change correctly the following day. During these hours, the internal gears are actively engaged to flip the date automatically, and forcing a manual change can cause severe internal damage.

---

## 4. POWER RESERVE & CARE

- **Daily Wear:** For the watch to stay wound overnight, it typically requires 8 hours of active wear during the day. If you have a sedentary job (e.g., sitting at a desk), the rotor may not spin enough to fully charge the spring; you may need to give the crown a few manual turns in the evening.
- **Magnetism:** Keep your watch away from strong magnets (such as tablets, speakers, and magnetic clasps). Magnetic fields can magnetize the internal mechanism and cause the watch to malfunction or run extremely fast. If this happens, the watch will require a professional demagnetization service to fix it.
- **Water:** Always ensure the crown is pushed back in tightly before any contact with water.
- **Servicing:** This watch is a precision device with many moving parts lubricated with special oils. To maintain its accuracy and smooth operation, we recommend having the watch overhauled and serviced every 18-24 months. Please send your watch directly to STORM for official servicing.