TIME

AM indicator.

BUTTONS

A

B

PM indicator.

DATE

BUTTONS

A

B

Date shown is February 20th.

READING THE TIME

Press Button A once to view the time.

READING THE DATE

Press Button A twice to view the date.
Date changes automatically at 12 AM.

SETTING THE TIME

Press button A once then Press button B to enter setting mode.
(HOUR will flash)
Press A to advance the HOUR. Then press B to set.
(MINUTE will flash)
Press A to advance the MINUTE. Then press B to set.
(MONTH will flash)
Press A to advance the MONTH. Then press B to set.
(DAY will flash)
Press A to advance the DAY. Then press B to set and EXIT.

Note: AM indicator will switch on at twelve midnight.
            PM indicator will switch on at twelve midday.
            Date changes at 12 AM midnight.