


STORM



DIGIKO



FEATURES

Time, Month, Date, Second, Year, 12/24Hr 50M Water Resistant

READING THE TIME/DATE/SECOND

Mode sequence

TIME - MONTH/DATE - SECOND

Press A button once to view the time.

Press A button twice to view date/month.

Press A button three times to view second.

SETTING THE "TIME" AND "DATE"

Press A button to view the time.

While time is displayed, press and hold the B button until HOUR flashes, you are now in setting mode.

While digits are flashing, press B to select the setting mode: HOUR - MINUTE - MONTH DATE - YEAR - 12/24 HR - Exit.

While the desired setting mode is flashing, press A repeatedly

to advance digits.

Press B to set and move to next sequence, repeat for all setting modes. When LED display switches off, all setting is

automatically saved.

Repeat the above steps for all setting sequence.

Note: If 12 hour format is chosen, Yellow light will be displayed to represent PM.

Note: Battery life will depend on usage.