
STORM



FRONT

SETTING THE TIME & DATE

Press Button A once to illuminate the time.

Press and hold Button B for 3 seconds to enter setting mode, the second should flash to indicate it is in setting mode.

Press Button A to reset the second, press Button B to set the HOUR. To change, press Button A until at the desired HOUR.

Note: The white AM indicator will light at twelve AM.

Once HOUR is set, press Button B to advance to MINUTE mode.
Use Button A to change to the desired MINUTE.
Once set press Button B to advance to DATE mode.

Note: The green date indicator will light to indicate watch is now showing the date.

Press Button A to set the desired MONTH, press Button B to advance to setting the DATE. Press Button A to change to the desired DATE. Once finished to EXIT press Button B.

READING THE TIME

Press Button A once to view the TIME

Read the dial.

The 12 lights show the HOUR (Example shows 8am).

Read the bottom box.

The small square at the bottom of the dial shows the MINUTES (Example shows 59 minutes past).

The lights in the middle of the dial indicate the seconds.

Note: The bottom white light shows AM when lit.

The 12 lights show the MONTH (Example shows October) Read the bottom box.

Read the dial.

READING THE DATE

Press button A twice to view the DATE.

The small square at the bottom of the dial shows the DAY (Example shows 28th day).

The green light will indicate the watch is in DATE mode.

READING THE SECOND

Press Button A three times to view the SECOND.

BACK